



38-39/6-010

III. No.	Part No.	DESCRIPTION	Qty.	Change Point	REMARKS
DISTRIBUTOR					
	AXE 281	DISTRIBUTOR ASSEMBLY	1		1300
	12A 1618	DISTRIBUTOR ASSEMBLY	1		1000 & 1001
	AXE 504	DISTRIBUTOR ASSEMBLY	1		Minimatic
1	GRA 101	Arm—rotor	1		
2	GSC 101	Condensor	1		
3	37H 3981	Terminal—bush and lead	1		
4	GDC 102	Cap—distributor	1		
5	17H 5065	Brush and spring	1		
6	GCS 101	Contact set	1		
7	AXE 652	Plate—base	1		1000, 1001 & Minimatic
7	AXE 653	Plate—base	1		1300
9	37H 4315	Spring—automatic advance	1		1300
9	17H 8865	Spring—automatic advance	1		1000 & 1001
9	27H 6988	Spring—automatic advance	1		Minimatic
10	AXE 654	Cam	1		1000 & 1001
10	AXE 655	Cam	1		1300
10	AXE 662	Cam	1		Minimatic
11	AXE 656	Weight	2		
13	37H 1772	Unit—vacuum	1		1300
13	37H 4118	Unit—vacuum	1		1000 & 1001
13	37H 3972	Unit—vacuum	1		Minimatic
14	AXE 657	Clip—cover	2		
15	3H 2138	Plate—clamping	1		
16	AXE 658	Bushing	1		
17	AXE 659	Dog—driving	1		
18	27H 6547	'O' ring—oil seal	1		
	17H 5106	Set sundries	1 set		
19	HZS 0406	Screw	2		
20	PWZ 104	Washer	2		
21	AXE 282	Cable (H.T.) lead	1		
22	8G 726	Cover—waterproof	1		
23	AXE 111	Cover—protective	1		
24	GCL 101	Coil—ignition	1		
25	8G 727	Cover—coil—waterproof	1		
26	AXE 660	Bracket—coil mounting	1		1000
27	FNZ 105	Nut	2		
28	LWZ 405	Washer—shakeproof	2		
29	PWZ 305	Washer—plain	2		
30	NH 604041	Nut	1		
31	LWZ 304	Washer—spring	1] 1000
32	AXE 661	Bolt—clamping	1		
33	37H 4229 M	Pipe—vacuum control—584mm long	A/R		Supplied in multiples of metres
36	12B 2095	Connection—vacuum pipe	2		
34	AXE 109	Bracket	1] 1001, 1300 & Minimatic
35	HZS 0506	Bolt	1		